Assemble the enclosure Note: Fit the exhaust fan in the right direction. Use the exhaust fan and its power adapter delivered with the enclosure. Do not use other fans or power adapters. Otherwise, the enclosure parts or the machine may be damaged.


XTOOL

Portable Enclosure Assembly Guide


XTOOL



List of items



Meet the enclosure



Precautions

- The portable enclosure is applicable only to isolate you from and exhaust the smoke and fumes generated during laser cutting and engraving. Do not use it for other purposes.
- The enclosure is made of flame-retardant materials, but it can't completely keep flames from spreading. Do not leave the machine unattended during laser processing.
- The blue light filter of the observation window can filter out most of the blue laser beams, but the high-intensity beams may still hurt your eyes. It is recommended that you wear a pair of professional laser safety goggles during observation.
- \cdot When fitting the sides, ensure that the bright sides face outward and the dull ones face inward.
- · The enclosure may be damaged when being pressed or scraped. Handle it with care.